Mandis shop

PackardBell STUDIO

Original		Rechange	
POWER	Power		Power
Mute	Mute	MUTE	Mute
Home	Home	HOME SMART	Smart
Home	Home	TOP MENU MENU	Menu
	Up		Up
	Left		Left
Play Enter	Play / Enter	OK	Ok
Play Enter	Play / Enter	PLAY MODE	Play
	Right		Right
	Down		Down
Vol+	Vol +	+ VOL	Vol +
Vol-	Vol -	VOL −	Vol -
Info	Info	DISPLAY INFO	Info
Back	Back	RETURN BACK	Back
SETUP	Setup	SETTINGS OPT	Options
	List	DISC NAV LIST	List
Repeat	Repeat	REPEAT TEXT	Text

Original		Rechange	
Angle	Angle	PICTURE FORMAT	Format
Subtitle	Subtitle	AD SUBT	Subt
Audio/EQ	Audio / EQ	SOUND DUAL	Dual
	TV / Radio	SEARCH TV/R	TV/R
Zoom	Zoom	ZOOM	Eject
	Pause		Pause
	Stop		Stop
Rotate	Rotate	TIMER AV	AV
	I<<		I<<
	<<		<<
	>>		>>
	>>I		>>I

https://tout-telecommande.fr/fr/Packard-Bell/1595-707-telecommande-remplacement-pour-Packard-Bell-Studio.html