Original		Rechange	
	Power		Power
TV/TEXT	Tv/Text	REPEAT TEXT	Text
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
INPUT SELECT AV	AV/Input Select	TIMER AV	AV
-/--	-/--	-/-- GUIDE	Guide
TRACKING/V-LOCK +	Tracking/V-Lock+	+ CH	Ch +
-	Tracking/V-Lock-	CH -	Ch -
VOLUME +	Vol+	+ VOL	Vol +

Original		Rechange	
	Vol-	VOL -	Vol -
SEARCH	Search	SHIFT + SEARCH TV/R	Shift + TV/R
SHOW VIEW	Show View	HOME SMART	Smart
OSD/DISPLAY	OSD/Display	DISPLAY INFO	Info
REPLAY	Replay	FAV PRE-CH	Pre Ch
DIRECT TV REC	Direct Tv Rec	SEARCH TV/R	TV/R
INDEX	I<< Index		I<<
INDEX	Index >>I		>>I
REC	Rec	REC MODE	Rec
	Pause/Step		Pause
MENU	Menu	TOP MENU MENU	Menu
OK	OK	OK	Ok
	Play/Up	PLAY MODE	Play
	Stop/Down		Stop
	>>/Right		>>
	<</Left		<<
SP/LP	SP/LP	PICTURE FORMAT	Format

Original		Rechange	
TIMER REC	Timer Rec	ECO 3D	3D
PROG/CHECK	Prog/Check	PROG SLEEP	Sleep
RESET	Reset	RETURN BACK	Back
AUDIO	Audio	SOUND DUAL	Dual
VPS/PDC	VPS/PDC	AD SUBT	Subt
AV LINK	AV Link	APP MEDIA	Media
TV ASPECT	TV Aspect	ZOOM ⏏	Eject
	Still Album	DISC NAV LIST	List
	Up	▲	Up
	Down	▼	Down
DATE +	Date+	▶	Right
DATE −	Date-	◀	Left
ON +	On+	A	Red
ON −	On-	B	Green
OFF +	Off+	C	Yellow
OFF −	Off-	D	Blue
CANCEL	Cancel	E-MANUAL D.MENU	D. Menu

Original		Rechange	
EXIT	Exit	CLEAR EXIT	Exit

Original		Rechange	
	Power		Power
TV/TEXT	TV/Text	REPEAT TEXT	Text
TRACKING/V-LOCK	CH+	+ CH	Ch +
	CH-	CH −	Ch -
VOLUME +	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	-/-- GUIDE	Guide

Original		Rechange	
INPUT SELECT AV	AV Input Select	TIMER AV	AV
	Red	A	Red
+ DATE	Green	B	Green
+ ON	Yellow	C	Yellow
+ OFF	Blue	D	Blue