Original		Rechange	
POWER TV	Power Tv	SHIFT + POWER	Shift + Power
TV/AV	Tv/AV Tv	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
VOLUME	Volume+ Tv	+ VOL	Vol+
	CH+ Tv	SHIFT + + CH PAGE	Shift + CH+ /
	Volume- Tv	VOL −	Vol-
	CH- Tv	SHIFT + CH PAGE −	Shift + CH- /
POWER	Power	POWER	Power
OSD	OSD	MEDIA DISPLAY	Display / Media
INDE	I< Index	PRESET-	I<< / Preset-
DEX	Index >I	PRESET+	>>I / Preset+
TIMER REC	Timer Rec	TIMER SLEEP	Sleep / Timer
CHECK	Check	LIST SMART	Smart / List
TRANSMIT	Transmit	EQ SUBTITLE	Subtitle / EQ
PLAY	Play	SLOW	Play / Slow
SP/LP	SP/LP	FORMAT PICTURE	Picture / Format
AUDIO OUT	Audio Out	LANG I/II AUDIO	Audio / Lang I/II
AV LINK	AV Link	PROGRAM TV/RADIO	TV/Radio / Program

Original		Rechange	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
REW	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
STOP	Stop	HOLD	Stop / Hold
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
0	0	HDMI - SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
MENU	Menu	HOME MENU	Menu / Home
TRACKING	Up/Trackin/V-Lock	+	Up

Original	Rechange	Original	Rechange
V-LOCK+ EXIT — Exit	CLEAR EXIT CANCEL — Exit / Cancel / Clear		
PAUSE/ STILL — Pause/Still	STEP-FREEZE — Pause / Step / Freeze		
SLOW — Slow	SHIFT + SLOW — Shift + Play /		
+	CH PAGE + — CH+ / Page+		
DISPLAY — Left/Display	Left		
RESET STORE — Store/Reset	OK — OK		
ZERO STOP — Right/Zero Stop	Right		
REC — Rec	REC MODE — Rec / Rec Mode		
-	CH PAGE − — CH- / Page-		
Down/Tracking/V-Lock-	Down		