Original	Rechange	Original	Rechange
Power Tv	Power	Back Tv	Back
Av Tv	AV	Ch+ Tv	Ch +
Menu Tv	Menu	Ch- Tv	Ch -
Up Tv	Up	▼P[≡] Tv	I <<
Down Tv	Down	▲P[ ] Tv	>>I
Left Tv	Left	<< Tv	<<
Right Tv	Right	>> Tv	>>
Ok Tv	Ok	Stop Tv	Stop
Info Tv	Info	Play Tv	Play
Exit Tv	Exit	1 Tv	1
Red Tv	Red	2 Tv	2
Green Tv	Green	3 Tv	3
Yellow Tv	Yellow	4 Tv	4
Blue Tv	Blue	5 Tv	5
Vol + Tv	Vol +	6 Tv	6
Vol - Tv	Vol -	7 Tv	7
Mute Tv	Mute	8 Tv	8

Original		Rechange	
9	9 Tv	9	9
0	0 Tv	0	0
* TXT	Text Tv	REPEAT TEXT	Text
# HELP	#Help Tv	FAV PRE-CH	Pre Ch
▼P [≡]	▼P [≡] Tv2	SHIFT + I<<	Shift + I<<
▲P [ ]	▲P [ ] Tv2	SHIFT + >>I	Shift + >>I
●	Rec Tv2	SHIFT + REC MODE ●	Shift + Rec
▶	Play Tv2	SHIFT + PLAY MODE ▶	Shift + Play
AV	Av Tv2	SHIFT + TIMER AV	Shift + AV
<<	<< Tv2	SHIFT + <<	Shift + <<
>>	>> Tv2	SHIFT + >>	Shift + >>
⏻	Power Tv2	SHIFT + ⏻	Shift + Power
GUIDE	Guide Tv2	SHIFT + -/-- GUIDE	Shift + Guide
MENU	Menu Tv2	SHIFT + TOP MENU MENU	Shift + Menu
▲	Up Tv2	SHIFT + ▲	Shift + Up
◀	Left Tv2	SHIFT + ◀	Shift + Left
▶	Right Tv2	SHIFT + ▶	Shift + Right

Original		Rechange	
▼	Down Tv2	SHIFT + ▼	Shift + Down
OK	Ok Tv2	SHIFT + OK	Shift + Ok
INFO	Info Tv2	SHIFT + DISPLAY INFO	Shift + Info
●	Green Tv2	SHIFT + B	Shift + Green
●	Red Tv2	SHIFT + A	Shift + Red
EXIT	Exit Tv2	SHIFT + CLEAR EXIT	Shift + Exit
●	Yellow Tv2	SHIFT + C	Shift + Yellow
●	Blue Tv2	SHIFT + D	Shift + Blue
P.P	Back Tv2	SHIFT + RETURN BACK	Shift + Back
+ CH	Ch+ Tv2	SHIFT + + CH	Shift + Ch +
CH −	Ch- Tv2	SHIFT + CH −	Shift + Ch -
■	Stop Tv2	SHIFT + ■	Shift + Stop
⏸	Pause Tv2	SHIFT + ⏸	Shift + Pause
1	1 Tv2	SHIFT + 1	Shift + 1
2	2 Tv2	SHIFT + 2	Shift + 2
3	3 Tv2	SHIFT + 3	Shift + 3
4	4 Tv2	SHIFT + 4	Shift + 4

Original		Rechange		Original	Rechange
5	5 Tv2	SHIFT + 5	Shift + 5		
6	6 Tv2	SHIFT + 6	Shift + 6		
7	7 Tv2	SHIFT + 7	Shift + 7		
8	8 Tv2	SHIFT + 8	Shift + 8		
9	9 Tv2	SHIFT + 9	Shift + 9		
0	0 Tv2	SHIFT + 0	Shift + 0		
* TXT	Text Tv2	SHIFT + REPEAT TEXT	Shift + Text		
# HELP	#Help Tv2	SHIFT + FAV PRE-CH	Shift + Pre Ch		

Original	Rechange	Original	Rechange
Power DVD	Power	Mute DVD/ DVR	Mute
AV DVD/ DVR	AV	Back DVD/ DVR	Back
Guide DVD/ DVR	Guide	Ch+ DVD/ DVR	Ch +
Menu DVD/ DVR	Menu	▼P[≡] DVD/ DVR	I <<
Info DVD/ DVR	Info	Ch- DVD/ DVR	Ch -
Exit DVD/ DVR	Exit	▲P[ ] DVD/ DVR	>>I
Up DVD/ DVR	Up	<< DVD/ DVR	<<
Down DVD/ DVR	Down	>> DVD/ DVR	>>
Left DVD/ DVR	Left	Play DVD/ DVR	Play
Right DVD/ DVR	Right	Pause DVD/ DVR	Pause
Ok DVD/ DVR	Ok	Stop DVD/ DVR	Stop
Red DVD/ DVR	Red	Rec DVD/ DVR	Rec
Green DVD/ DVR	Green	1 DVD/ DVR	1
Yellow	Yellow	2 DVD/ DVR	2
Blue DVD/ DVR	Blue	3 DVD/ DVR	3
Vol + DVD/ DVR	Vol +	4 DVD/ DVR	4
Vol - DVD/ DVR	Vol -	5 DVD/ DVR	5

Original		Rechange	
6	6 DVD/ DVR	6	6
7	7 DVD/ DVR	7	7
8	8 DVD/ DVR	8	8
9	9 DVD/ DVR	9	9
0	0 DVD/ DVR	0	0
* TXT	Text DVD/ DVR	REPEAT TEXT	Text
# HELP	#Help DVD/ DVR	FAV PRE-CH	Pre Ch
	Power DVR	SHIFT +	Shift + Power

Original	Rechange

Original	Rechange	Original	Rechange
Power	Power	Mute	Mute
Menu	Menu	Back	Back
Guide	Guide	Ch+ SAT/ CABLE	Ch +
AV SAT/ CABLE	AV	Ch- SAT/ CABLE	Ch -
Up SAT/ CABLE	Up	<< SAT/ CABLE	<<
Down	Down	>> SAT/ CABLE	>>
Left SAT/ CABLE	Left	Stop SAT/ CABLE	Stop
Right	Right	Rec SAT/ CABLE	Rec
Ok SAT/ CABLE	Ok	Play SAT/ CABLE	Play
Info SAT/ CABLE	Info	Pause	Pause
Exit SAT/ CABLE	Exit	1 SAT/ CABLE	1
Red SAT/ CABLE	Red	2 SAT/ CABLE	2
Green	Green	3 SAT/ CABLE	3
Yellow SAT/ CABLE	Yellow	4 SAT/ CABLE	4
Blue SAT/ CABLE	Blue	5 SAT/ CABLE	5
Vol +	Vol +	6 SAT/ CABLE	6
Vol - SAT/ CABLE	Vol -	7 SAT/ CABLE	7

Original		Rechange	
8	8 SAT/ CABLE	8	8
9	9 SAT/ CABLE	9	9
0	0 SAT/ CABLE	0	0
# HELP	#Help	FAV PRE-CH	Pre Ch
* TXT	Text SAT/ CABLE	REPEAT TEXT	Text

Original	Rechange

Original	Rechange	Original	Rechange
Power DVBT	Power	Ch+ DVBT	Ch +
Gui de DVBT	Gui de	Ch- DVBT	Ch -
Menu DVBT	Menu	Pause DVBT	Pause
Up DVBT	Up	1 DVBT	1
Down DVBT	Down	2 DVBT	2
Left DVBT	Left	3 DVBT	3
Ri ght DVBT	Ri ght	4 DVBT	4
Ok DVBT	Ok	5 DVBT	5
I nfo DVBT	I nfo	6 DVBT	6
Red DVBT	Red	7 DVBT	7
Green DVBT	Green	8 DVBT	8
Yel l ow DVBT	Yel l ow	9 DVBT	9
Bl ue DVBT	Bl ue	0 DVBT	0
Vol + DVBT	Vol +	Power VCR	Shi f t + Power
Vol - DVBT	Vol -	Av VCR	AV
Mut e DVBT	Mut e	<< VCR	<<
Back DVBT	Back	St op VCR	St op

Original	Rechange	Original	Rechange
>> VCR	>>	Back VCR	SHIFT + RETURN BACK Shift + Back
Play VCR	PLAY MODE Play	Ch+ VCR	SHIFT + CH Shift + Ch +
Rec VCR	REC MODE Rec	Ch- VCR	SHIFT + CH Shift + Ch -
Pause VCR	SHIFT + Shift + Pause	1 VCR	SHIFT + 1 Shift + 1
Guide VCR	SHIFT + GUIDE Shift + Guide	2 VCR	SHIFT + 2 Shift + 2
Menu VCR	SHIFT + TOP MENU MENU Shift + Menu	3 VCR	SHIFT + 3 Shift + 3
Up VCR	SHIFT + Shift + Up	4 VCR	SHIFT + 4 Shift + 4
Down VCR	SHIFT + Shift + Down	5 VCR	SHIFT + 5 Shift + 5
Left VCR	SHIFT + Shift + Left	6 VCR	SHIFT + 6 Shift + 6
Right VCR	SHIFT + Shift + Right	7 VCR	SHIFT + 7 Shift + 7
Ok VCR	SHIFT + OK Shift + Ok	8 VCR	SHIFT + 8 Shift + 8
Info VCR	SHIFT + DISPLAY INFO Shift + Info	9 VCR	SHIFT + 9 Shift + 9
Exit VCR	CLEAR EXIT Exit	0 VCR	SHIFT + 0 Shift + 0
Red VCR	SHIFT + A Shift + Red	Text VCR	REPEAT TEXT Text
Green VCR	SHIFT + B Shift + Green	#Help VCR	FAV PRE-CH Pre Ch
Yellow VCR	SHIFT + C Shift + Yellow		
Blue VCR	SHIFT + D Shift + Blue		