Original	Rechange
Standby/On	Power
Power CD/SACD Player	Smart / List
Play CD/SACD	Play / Slow
Pause CD/SACD Player	Pause / Step / Freeze
I<< CD/SACD	I<< / Preset-
Stop CD/SACD	Stop / Hold
>>I CD/SACD	>>I / Preset+
Power Network Audio Player	Shift + Smart / List
Play Network Audio Player	Shift + Play /
Pause Network Audio Player	Shift + Pause / Step /
Source Network Audio Player	AV / Input / RDS
I<< Network Audio Player	Shift + I<< / Preset-
Stop Network Audio Player	Shift + Stop /
>>I Network Audio Player	Shift + >>I / Preset+
Top Menu	D.Menu / Top
Now Playing	Info / Angle
Up	Up

Original	Rechange
Left	Left
Enter	OK
Right	Right
Setup	Setup / OPT /
Down	Down
Return	Back / Return
Volume+	Vol +
Mute	Mute / Dimmer
Volume-	Vol -
Phono	1
CD/SACD	2
Line 1	3
Line 2	4
Line 3	5
Line 4	6
Coaxial	7
Optical	8

Original	Rechange	Original	Rechange
DIRECT Direct	GUIDE EPG Guide / EPG / -/--		
LOUDNESS Loudness	HDMI - SAT 0 0		