Mandis shop

Pioneer CU-PD046

Original	Rechange
Standby / On	Power
Disc 1	1
Disc 2	2
Disc 3	3
Disc 4	4
Disc 5	5
Disc 6	6
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
Random	Blue / Prime Video / Random
<<	<< / Tune-
>>	>> / Tune+
Hi-Lite	Smart / List
I <<	I << / Preset-
>>I	>>I / Preset+
Program	TV/Radio / Program

Original	Rechange
Delete	Back / Return
Check	OK
Clear	Exit / Cancel / Clear

https://tout-telecommande.fr/fr/Pioneer/1696-930-Telecommande-de-remplacement-pour-Pioneer-CU-PD104.html