Mandis shop

REMCON2136

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| TUNER | Tuner | TUNER 6 | 6 | | |
| CD | CD | CD - STB 3 | 3 | | |
| DOWN I<< | I<</Down | PRESET- I<< | I<< / Preset- | | |
| UP >>I | >>I/Up | PRESET+ >>I | >>I / Preset+ | | |
| ▶II | Play | SLOW ▶ | Play / Slow | | |
| ▶II | Pause | STEP - FREEZE II | Pause / Step / Freeze | | |
| M-UP REPEAT | M-Up/Repeat | APP REPEAT | Green / APP / Repeat | | |
| MEMORY CLOCK | Memory/Clock | TIMER SLEEP | Sleep / Timer | | |
| STOP | Stop | HOLD ■ | Stop / Hold | | |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer | | |
| BAND | Band | PROGRAM TV/RADIO | TV/Radio / | | |
| POWER | Power | ⏻ | Power | | |
| – VOLU | Volume- | VOL – | Vol- | | |
| LUME + | Volume+ | + VOL | Vol+ | | |
| | | | | | |
| | | | | | |
| | | | | | |

https://tout-telecommandes.fr/fr/Roadstar/1067276-96946-telecommande-de-remplacement-pour-Roadstar-REMCON2136.html