| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| MUTE | Mute | MUTE | Mute |
| MODE | Mode | APP MEDIA | Media |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| -/-- | | SHIFT + -/-- GUIDE | Shift + Guide |
| BACK | Back | RETURN BACK | Back |
| NICAM/A2 | Nicam/A2 | SOUND DUAL | Dual |

| Original | | Rechange | |
|---|---|---|---|
| TXT/MIX | TXT/MIX | REPEAT TEXT | Text |
| TXT/MIX | Play | PLAY MODE | Play |
| TXT/MIX | Pause | | Pause |
| CANCEL | Stop | | Stop |
| REC | Rec | REC MODE | Rec |
| INDEX | >>/Index | | >> |
| HOLD | <<</Hold | | << |
| SIZE | I<< | | I<< |
| REVEAL | >>I | | >>I |
| CANCEL | Cancel | CLEAR EXIT | Exit |
| MENU | Menu | TOP MENU MENU | Menu |
| DTV/RADIO | DTV/Radio | SEARCH TV/R | TV/R |
| VOL+ | Vol+ | + VOL | Vol + |
| VOL- | Vol- | VOL – | Vol - |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |

| Original | | Rechange | |
|---|---|---|---|
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| CH+ | CH+ | + CH | Ch + |
| CH- | CH- | CH − | Ch - |
| FAV | FAV | FAV PRE-CH | Pre Ch |
| EPG | EPG | GUIDE | Guide |
| INFO | Info | DISPLAY INFO | Info |
| LIST | List | DISC NAV LIST | List |
| RED | Red | A | Red |
| GREEN | Green | B | Green |
| YELLOW | Yellow | C | Yellow |
| BLUE | Blue | D | Blue |
| SIZE | Size | PICTURE FORMAT | Format |
| REVEAL | Reveal | ECO 3D | 3D |
| SUBTITLE | Subtitle | AD SUBT | Subt |
| SUBPAGE | Subpage | TIMER AV | AV |
| FAV+ | FAV+ | SHIFT + + CH | Shift + Ch + |

| Original | | Rechange | |
|---|---|---|---|
| FAV- | FAV- | SHIFT + CH − | Shift + Ch - |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | Vol+ | Vol + |
| Mute | Mute | Vol- | Vol - |
| [ I ]/Menu | Menu | CH+ | Ch + |
| Exit | Exit | CH- | Ch - |
| Source | AV | Up | Up |
| 1 | 1 | Down | Down |
| 2 | 2 | Right | Right |
| 3 | 3 | Left | Left |
| 4 | 4 | OK | Ok |
| 5 | 5 | Recall | Back |
| 6 | 6 | Info | Info |
| 7 | 7 | EPG | Guide |
| 8 | 8 | Freeze | Options |
| 9 | 9 | Red | Red |
| 0 | 0 | Green | Green |
| Subtitle | Subt | Yellow | Yellow |
| Text | Text | Blue | Blue |

| Original | Rechange | | Original | Rechange |
|---|---|---|---|---|
| Audio | SOUND DUAL | Dual | | |
| I<</[≡+] | | I<< | | |
| >>I/[≡..] | | >>I | | |
| [≡i] | HOME SMART | Smart | | |
| Play | PLAY MODE | Play | | |
| Pause | | Pause | | |
| Stop | | Stop | | |
| REP/Rec | REC MODE | Rec | | |
| <</[≡o] | | << | | |
| >>/[≡?] | | >> | | |
| FAV | FAV PRE-CH | Pre Ch | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |