Original		Rechange	
POWER	Power		Power
DVD	DVD	D	Blue
TUNER	Tuner	B	Green
USB	USB	C	Yellow
AUX	AUX	A	Red
	Open/Close	ZOOM	Eject
SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Rechange	
REMAIN	Remain	HOME SMART	Smart
CANCEL	Cancel	APP MEDIA	Media
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PLAY	Pause		Pause
STEP	Step	SETTINGS OPT	Options
REPEAT	Repeat	REPEAT TEXT	Text
VOLUME	Vol +	VOL +	Vol +
VOLUME	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
TUNING	Tuning Up	CH +	Ch +
TUNING	Tuning Down	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu

Original		Rechange		Original	Rechange
RETURN	Return	RETURN BACK	Back		
PRESET	Preset Up		Up		
PRESET	Preset Down		Down		
SEEK UP	Right / Seek Up		Right		
SEEK DOWN	Left / Seek Down		Left		
ENTER	Enter	OK	Ok		
AUDIO	Audio	SOUND DUAL	Dual		
SUBTITLE	Subtitle	AD SUBT	Subt		
INFO	Info	DISPLAY INFO	Info		
EXIT	Exit	CLEAR EXIT	Exit		
P.SOUND	P. Sound	SHIFT + SOUND DUAL	Shift + Dual		
EQ	EQ	ECO 3D	3D		
MO/ST ZOOM	Zoom/Mo/ST	SHIFT + ZOOM	Shift + Eject		
AUTO SCAN ANGLE	Angle/Autoscan	-/-- GUIDE	Guide		