Mandis shop

RRMCG0144AWSA

| Original | | Rechange | |
|---|---|---|---|
| ON/ STAND-BY | On/Standby | | Power |
| VOLUME | Vol+ | VOL + | Vol + |
| VOLU | Vol- | VOL − | Vol - |
| X-BASS/ EQUALIZER | X-Bass/Equalizer | HOME SMART | Smart |
| VIDEO/AUX | Video/AUX | A | Red |
| TAPE (1↔2) | Tape (1↔2) | D | Blue |
| TUNER (BAND) | Tuner(Band) | B | Green |
| C D | CD | C | Yellow |
| | Rec/Pause Tape 2 | REC MODE | Rec |
| | << Tape 2 | << | << |
| | >> Tape 2 | >> | >> |
| TAPE 2 | Play Tape 2 | | Left |
| TAPE 1 | Play Tape 1 | | Right |
| TAPE 1 TAPE 2 | Stop Tape | OK | Ok |
| RESET | Tuner Preset Up | CH + | Ch + |
| PRES | Tuner Preset | CH − | Ch - |
| PTY. TI | PTY TI | RETURN BACK | Back |

| Original | | Rechange | |
|---|---|---|---|
| 1 | Disc CD 1 | 1 | 1 |
| 2 | Disc CD 2 | 2 | 2 |
| 3 | Disc CD 3 | 3 | 3 |
| DISC SKIP | Disc Skip | APP MEDIA | Media |
| | I<<|<< CD | << | I<< |
| | >>|>>I CD | >>I | >>I |
| | Stop CD | ■ | Stop |
| | Play CD | PLAY MODE ▶ | Play |
| MEMORY | Memory CD | ECO 3D | 3D |
| CLEAR | Clear | CLEAR EXIT | Exit |
| RANDOM | Random | SEARCH TV/R | TV/R |
| | Pause CD | II | Pause |

https://tout-telecommandes.fr/fr/Sharp/1061610-2982-telecommande-de-remplacement-pour-Sharp-RRMCG0144AWSA.html