Mandis shop

Sharp RRMCG0107AWSA

Original	Rechange
On/Standby	Power
Stop	Stop / Hold
Play	Play / Slow
Pause	Pause / Step / Freeze
Back/Random	Back / Return
I<</<<</Preset-	I<< / Preset-
Preset+/>>/>>	>>I / Preset+
Memory/Set	Setup / OPT /
Tuning-	<< / Tune-
Tuning+	>> / Tune+
Clear	Exit / Cancel / Clear
Timer/Set	D.Menu / Top
Timer	Shift + Sleep / Timer
Sleep	Sleep / Timer
Timer-	Down
Timer+	Up
Function	Menu / Home

Original	Rechange
Band	TV/Radio /
X-Bass/Equalizer	Sound / Title
3D Surround	Audio / Lang I/II
Vol-	Vol-
Vol+	Vol+

https://tout-telecommandes.fr/fr/Sharp/1066140-2464-telecommande-de-remplacement-pour-Sharp-RRMCG0107AWSA.html