Mandis shop

Sony RMT-CF15CPAD

Original	Rechange	Original	Rechange
Operate	Power	Tune-	<< / Tune-
Function	Menu / Home	Repeat	Green / APP / Repeat
Sleep	Sleep / Timer	Vol +	Vol +
1	1	Vol -	Vol -
2	2	Play	Play / Slow
3	3	Pause	Pause / Step / Freeze
4	4	Stop	Stop / Hold
5	5	I <<	I << / Preset-
6	6	>>I	>>I / Preset+
7	7	Folder-	CH- / Page-
8	8	Folder+	CH+ / Page+
9	9	Sound	Sound / Title
0/10	0	Mega Bass	Setup / OPT /
Mode	Display / Media		
+10	Guide / EPG / -/--		
Band	TV/Radio /		
Tune+	>> / Tune+		

https://tout-telecommande.fr/fr/Sony/10508-8519-telecommande-de-replacement-pour-Sony-RMT-CF15CPAD-A12730A.html