Mandis shop

Teac RC-1195

Original		Rechange	
STANDBY/ON	Standby / On		Power
	Dimmer	OK	Ok
FUNCTION	Function	SETTINGS OPT	Options
TIMER	Timer	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
FM/AM	FM / AM	HOME SMART	Smart
SHUFFLE FM MODE	FM Mode / Shuffle	SEARCH TV/R	TV/R
REPEAT PTY	PTY / Repeat	REPEAT TEXT	Text
MP3 RDS	RDS / MP3	APP MEDIA	Media
TUNI	I<< / Tuning -		I<<
JNING	>>I / Tuning +		>>I
PLAY/PAUSE	Play / Pause	PLAY MODE	Play
PLAY/PAUSE	Play / Pause		Pause
PRESET/F	Preset/Folder	CH –	Ch -
T/FOLDER	Preset/Folder Up	+ CH	Ch +
STOP	Stop		Stop
BASS	Bass		Left

Original		Rechange	
TREBLE	Treble		Right
VOLUME +	Volume (Bass/Treble) +	+ VOL	Vol +
–	Volume (Bass/Treble) -	VOL –	Vol -
MEMORY/ TIME SET	Memory / Time	TOP MENU MENU	Menu
MUTING	Muting	MUTE	Mute

https://tout-telecommandes.fr/fr/Teac/1058323-46292-telecommande-de-remplacement-pour-Teac-RC-1195.html