Mandis shop

Tcl MA06250AG18RC1

Original		Rechange	
	Power		Power
	Bluetooth	BLUETOOTH 9	9
	Mute	DIMMER MUTE	Mute / Dimmer
AUX	AUX	AUX - HDD 7	7
OPTICAL	Optical	OPT-TOOLS SETUP	Setup / OPT /
USB	USB	USB 8	8
HDMI	HDMI	HDMI - SAT 0	0
MUSIC	Music	TITLE SOUND	Sound / Title
MOVIE	Movie	FORMAT PICTURE	Picture / Format
DIALOG	Dialog	LANG I/II AUDIO	Audio / Lang I/II
+ TREBLE	Treble+		Up
+ BASS	Bass+	+ CH PAGE	CH+ / Page+
+ VOLUME	Volume+	+ VOL	Vol +
TREBLE −	Treble-		Down
BASS −	Bass-	CH PAGE −	CH- / Page-
VOLUME −	Volume-	VOL −	Vol -
	I<	PRESET-	I<< / Preset-

Original		Rechange	
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	>I	PRESET+	>>I / Preset+

https://tout-telecommande.fr/fr/Tcl/10825923-telecommande-remplacement-pour-Tcl-MA06250AG18RC1.html