Original		Rechange	
	Power MD		Power
	Direct Tuning	REPEAT TEXT	Text
DIMMER	Dimmer	FAV PRE-CH	Pre Ch
TV	TV	SEARCH TV/R	TV/R
CD	CD	C	Yellow
DVD	DVD	D	Blue
TUNER/ BAND	Tuner/Band	B	Green
TAPE	Tape	A	Red
VCR	VCR	HOME SMART	Smart
MD	MD	APP MEDIA	Media
VOL +	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
MUTING	Muting	MUTE	Mute
	Stop MD	■	Stop
	Play MD	PLAY MODE ▶	Play
	<<|<< MD	«	<<
	>>|>>| MD	»	>>

Original		Rechange	
	Up	▲	Up
	Down	▼	Down
	Right	▶	Right
	Left	◀	Left
ENTER	Enter	OK	Ok
MENU	Menu	E-MANUAL D.MENU	D. Menu
DISPLAY	Display	DISPLAY INFO	Info
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu
1	1 MD	1	1
2	2 MD	2	2
3	3 MD	3	3
4	4 MD	4	4
5	5 MD	5	5
6	6 MD	6	6
7	7 MD	7	7
8	8 MD	8	8
9	9 MD	9	9

Original		Rechange	
0	0 MD	0	0
≥10/-/--	>10/-/-- MD	-/-- GUIDE	Guide
TV/AV	Tv/AV	TIMER AV	AV
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH −	Ch -
⏻	Power TV	SHIFT + ⏻	Shift + Power
VOL ^	Tv Vol Up	SHIFT + + VOL	Shift + Vol +
TV v	Tv Vol Down	SHIFT + VOL −	Shift + Vol -
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3

Original		Rechange	
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
0	0 Tv	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/-- Tv	SHIFT + -/-- GUIDE	Shift + Guide

Original		Rechange	
	Power DVD		Power
	TV		TV/R
	VCR		Smart
	Tuner/Band		Green
	Tape		Red
	MD		Media
	CD		Yellow
	DVD		Blue
	Play DVD		Play
	I<<</<< DVD		<<
	Stop DVD		Stop
	>>/>>I DVD		>>
	Top Menu/Disc/Deck		Menu
	Display		Info
	Menu		D. Menu
	Up		Up
	Down		Down

Original		Rechange	
	Right		Right
	Left		Left
	Enter		Ok
	Stereo		Dual
	Surround		Options
	SFC		Subt
	Test		Back
	Delay		Format
	Level		3D
	+		Ch +
	-		Ch -
	1 DVD		1
	2 DVD		2
	3 DVD		3
	4 DVD		4
	5 DVD		5
	6 DVD		6

Original		Rechange		Original	Rechange
7	7 DVD	7	7		
8	8 DVD	8	8		
9	9 DVD	9	9		
0	0 DVD	0	0		
≥10/-/--	>10/- / - - DVD	-/-- GUIDE	Gui de		
VOL +	Vol +	+ VOL	Vol +		
VOL −	Vol -	VOL −	Vol -		
MUTING	Mut i ng	MUTE	Mut e		

Original		Rechange	
	Power CD		Power
	TV	SEARCH TV/R	TV/R
	VCR	HOME SMART	Smart
	CD	C	Yellow
	DVD	D	Blue
	Tape	A	Red
	MD	APP MEDIA	Media
	Tuner/Band	B	Green
	Stop CD		Stop
	I<<</<< CD	<<	<<
	>>/>>I CD	>>	>>
	Play CD	PLAY MODE	Play
	Menu	E-MANUAL D.MENU	D. Menu
	Display	DISPLAY INFO	Info
	Top Menu/Disc/Deck	TOP MENU MENU	Menu
	Up		Up
	Down		Down

Original		Rechange	
	Right		Right
	Left		Left
	Enter	OK	Ok
	Stereo	SOUND DUAL	Dual
	Surround	SETTINGS OPT	Options
	SFC	AD SUBT	Subt
	Test	RETURN BACK	Back
	Delay	PICTURE FORMAT	Format
	Level	ECO 3D	3D
	+	+ CH	Ch +
	-	CH −	Ch -
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Muting	MUTE	Mute
	Power Tape	SHIFT +	Shift + Power
	Stop Tape	SHIFT +	Shift + Stop
	Play Tape	SHIFT + PLAY MODE	Shift + Play

Original	Rechange	Original	Rechange
I <<| << Tape	SHIFT + « Shift + <<		
>>| >>I Tape	SHIFT + » Shift + >>		
Top Menu/ Disc/ Deck	SHIFT + TOP MENU MENU Shift + Menu		
1 CD- Tape	1 1		
2 CD- Tape	2 2		
3 CD- Tape	3 3		
4 CD- Tape	4 4		
5 CD- Tape	5 5		
6 CD- Tape	6 6		
7 CD- Tape	7 7		
8 CD- Tape	8 8		
9 CD- Tape	9 9		
0 CD- Tape	0 0		
>10/ - / - - CD- Tape	-/-- GUIDE Guide		
Direct Tuning/ Disc Ente	REPEAT TEXT Text		

Original		Rechange	
	Power VCR		Power
DIMMER	Dimmer	FAV PRE-CH	Pre Ch
VCR	VCR	HOME SMART	Smart
TAPE	Tape	A	Red
TV	TV	SEARCH TV/R	TV/R
CD	CD	C	Yellow
DVD	DVD	D	Blue
TUNER/ BAND	Tuner/Band	B	Green
MD	MD	APP MEDIA	Media
	Stop		Stop
	I <<<<		<<
	>>>> I		>>
	Play	PLAY MODE	Play
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4

Original		Rechange	
5	5 VCR	5	5
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
≥10/-/--	>10/-/-- VCR	-/-- GUIDE	Guide
DIRECT TUNING DISC ENTER	Direct Tuning/Disc Ente	REPEAT TEXT	Text
VOL +	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
MUTING	Muting	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu

1/2

Original	Rechange
Display	Info
Menu	D. Menu
Stereo	Dual
Surround	Options
SFC	Subt
Test	Back
Delay	Format
Level	3D
+	Ch +
-	Ch -
Power Tuner / Band	Shift + Power
1 Tuner / Band	Shift + 1
2 Tuner / Band	Shift + 2
3 Tuner / Band	Shift + 3
4 Tuner / Band	Shift + 4
5 Tuner / Band	Shift + 5
6 Tuner / Band	Shift + 6

Original	Rechange
7 Tuner / Band	Shift + 7
8 Tuner / Band	Shift + 8
9 Tuner / Band	Shift + 9
0 Tuner / Band	Shift + 0
>10/ - / - -	Shift + Guide