| Original | | Rechange | |
|---|---|---|---|
| | Power TV | | Power |
| | Mute TV TV | DIMMER MUTE | Mute / Dimmer |
| | Play/Save TV | SLOW | Play / Slow |
| | Pause TV | STEP-FREEZE | Pause / Step / Freeze |
| | Stop TV | HOLD | Stop / Hold |
| | Rec TV | REC MODE | Rec / Rec Mode |
| | <<Tuner- TV | TUNE- | << / Tune- |
| | >>Tuner+ TV | TUNE+ | >> / Tune+ |
| | PR-/I<< TV | PRESET- | I<< / Preset- |
| | PR+/>>I TV | PRESET+ | >>I / Preset+ |
| | Level TV | TITLE SOUND | Sound / Title |
| | Subwoofer TV | LANG I/II AUDIO | Audio / Lang I/II |
| | Equalizer TV | EQ SUBTITLE | Subtitle / EQ |
| | Surround TV | SURROUND | Eject / Surround |
| | Night TV | TIMER SLEEP | Sleep / Timer |
| | Setup TV | OPT-TOOLS SETUP | Setup / OPT / |
| | Menu TV TV | HOME MENU | Menu / Home |

| Original | | Rechange | |
|---|---|---|---|
| | Up TV | | Up |
| | Left/RDS TV | | Left |
| | OK TV | OK | OK |
| | Right/PTY TV | | Right |
| | Clear TV | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Down TV | | Down |
| | Back/ST-Mono | RETURN BACK | Back / Return |
| | Vol+ TV TV | + VOL | Vol+ |
| | PR+/>>I TV | + CH PAGE | CH+ / Page+ |
| | Vol- TV TV | VOL − | Vol- |
| | PR-/I<< TV | CH PAGE − | CH- / Page- |
| | 1 Tv | TV 1 | 1 |
| | 2 TV | DVD 2 | 2 |
| | 3 TV | CD-STB 3 | 3 |
| | 4 TV | VIDEO 4 | 4 |
| | 5 TV | TAPE 5 | 5 |
| | 6 TV | TUNER 6 | 6 |

| Original | Rechange |
|---|---|
| 7 TV | 7 |
| 8 TV | 8 |
| 9 TV | 9 |
| Guide TV | Guide / EPG / -/-- |
| 0 TV | 0 |
| Tape- CD | Red / Netflix / Search |
| AUX1 (VCR) | Green / APP / Repeat |
| Aux2 (SAT- Cable | Yellow / YouTube / Repeat |
| Power AUX1 | Shift + Power |
| Play/ Save AUX1 | Shift + Play / |
| Pause AUX1 | Shift + Pause / Step / |
| Stop AUX1 | Shift + Stop / |
| Rec AUX1 | Shift + Rec / Rec Mode |
| <</ Tuner - | Shift + << / |
| >>/ Tuner + | Shift + >> / |
| PR- / I <<AUX1 | Shift + I << / Preset- |
| PR+/ >>I AUX1 | Shift + >>I / Preset+ |

| Original | Rechange |
|---|---|
| Up AUX1 | Shift + Up |
| Left / RDS AUX1 | Shift + Left |
| OK AUX1 | Shift + OK |
| Right / PTY AUX1 | Shift + Right |
| Down AUX1 | Shift + Down |
| PR+/ >>I AUX1 | Shift + CH+ / |
| PR- / I <<AUX1 | Shift + CH- / |
| 1 AUX1 | Shift + 1 |
| 2 AUX1 | Shift + 2 |
| 3 AUX1 | Shift + 3 |
| 4 AUX1 | Shift + 4 |
| 5 AUX1 | Shift + 5 |
| 6 AUX1 | Shift + 6 |
| 7 AUX1 | Shift + 7 |
| 8 AUX1 | Shift + 8 |
| 9 AUX1 | Shift + 9 |
| Guide AUX1 | Shift + Guide / EPG / -/-- |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| 0 AUX1 | SHIFT + HDMI - SAT 0 | Shift + 0 | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power DVD6CH | Power | Up DVD6CH | Up |
| Mute DVD6CH | Mute / Dimmer | Left / RDS | Left |
| Play/Save | Play / Slow | OK DVD6CH | OK |
| Pause DVD6CH | Pause / Step / Freeze | Right / PTY | Right |
| Stop DVD6CH | Stop / Hold | Clear DVD6CH | Exit / Cancel / Clear |
| Rec DVD6CH | Rec / Rec Mode | Down DVD6CH | Down |
| <<Tuner- | << / Tune- | Back/St-Mono | Back / Return |
| >>Tuner+ | >> / Tune+ | Vol + DVD6CH | Vol + |
| PR- / I << | I << / Preset- | PR+/ >>I | CH+ / Page+ |
| PR+/ >>I | >>I / Preset+ | Vol - DVD6CH | Vol - |
| Level DVD6CH | Sound / Title | PR- / I << | CH- / Page- |
| Subwoofer | Audio / Lang I/II | 1 DVD6CH | 1 |
| Equalizer | Subtitle / EQ | 2 DVD6CH | 2 |
| Surround | Eject / Surround | 3 DVD6CH | 3 |
| Night DVD6CH | Sleep / Timer | 4 DVD6CH | 4 |
| Setup DVD6CH | Setup / OPT / | 5 DVD6CH | 5 |
| Menu DVD6CH | Menu / Home | 6 DVD6CH | 6 |

| Original | Rechange |
|---|---|
| 7 DVD6CH | 7 |
| 8 DVD6CH | 8 |
| 9 DVD6CH | 9 |
| Guide DVD6CH | Guide / EPG / -/-- |
| 0 DVD6CH | 0 |
| Tape- CD | Red / Netflix / Search |
| AUX1 (VCR) | Green / APP / Repeat |
| Aux2 (SAT- Cable | Yellow / YouTube / Repeat |
| Power Tape- CD | SHIFT + Power |
| Play/ Save | SHIFT + Shift + Play / |
| Pause Tape- CD | SHIFT + Shift + Pause / Step / |
| Stop Tape- CD | SHIFT + Shift + Stop / |
| Rec Tape- CD | SHIFT + Shift + Rec / Rec Mode |
| <</ Tuner- | SHIFT + Shift + << / |
| >>/ Tuner + | SHIFT + Shift + >> / |
| PR- / I << | SHIFT + Shift + I << / Preset- |
| PR+/ >>I | SHIFT + Shift + >>I / Preset+ |

| Original | Rechange |
|---|---|
| Up Tape- CD | SHIFT + Shift + Up |
| Left/ RDS Tape- CD | SHIFT + Shift + Left |
| OK Tape- CD | SHIFT + Shift + OK |
| Right/ PTY | SHIFT + Shift + Right |
| Down Tape- CD | SHIFT + Shift + Down |
| Back/ ST- Mono Tape- CD | SHIFT + Shift + Back / Return |
| PR+/ >>I | SHIFT + Shift + CH+ / |
| PR- / I << | SHIFT + Shift + CH- / |
| 1 Tape- CD | SHIFT + Shift + 1 |
| 2 Tape- CD | SHIFT + Shift + 2 |
| 3 Tape- CD | SHIFT + Shift + 3 |
| 4 Tape- CD | SHIFT + Shift + 4 |
| 5 Tape- CD | SHIFT + Shift + 5 |
| 6 Tape- CD | SHIFT + Shift + 6 |
| 7 Tape- CD | SHIFT + Shift + 7 |
| 8 Tape- CD | SHIFT + Shift + 8 |
| 9 Tape- CD | SHIFT + Shift + 9 |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| 0 Tape- CD | SHIFT + HDMI - SAT 0 | Shift + 0 | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Rechange |
|---|---|
| Power TUNER | Power |
| Mute TUNER | Mute / Dimmer |
| Play/Save | Play / Slow |
| Pause TUNER | Pause / Step / Freeze |
| Stop TUNER | Stop / Hold |
| <<Tuner- | << / Tune- |
| >>Tuner+ | >> / Tune+ |
| PR-/I<< TUNER | I<< / Preset- |
| PR+/>>I TUNER | >>I / Preset+ |
| Level TUNER | Sound / Title |
| Subwoofer | Audio / Lang I/II |
| Equalizer | Subtitle / EQ |
| Surround | Eject / Surround |
| Night TUNER | Sleep / Timer |
| Setup TUNER | Setup / OPT / |
| Menu TUNER | Menu / Home |
| Up TUNER | Up |

| Original | Rechange |
|---|---|
| Left/RDS TUNER | Left |
| OK TUNER | OK |
| Right/PTY | Right |
| Clear TUNER | Exit / Cancel / Clear |
| Down TUNER | Down |
| Back/St-Mono | Back / Return |
| Vol + TUNER | Vol + |
| PR+/>>I TUNER | CH+ / Page+ |
| Vol - TUNER | Vol - |
| PR-/I<< TUNER | CH- / Page- |
| 1 TUNER | 1 |
| 2 TUNER | 2 |
| 3 TUNER | 3 |
| 4 TUNER | 4 |
| 5 TUNER | 5 |
| 6 TUNER | 6 |
| 7 TUNER | 7 |

| Original | Rechange |
|---|---|
| 8 TUNER | 8 |
| 9 TUNER | 9 |
| Guide TUNER | Guide / EPG / -/-- |
| 0 TUNER | 0 |
| Tape- CD | Red / Netflix / Search |
| AUX1 (VCR) | Green / APP / Repeat |
| Aux2 (SAT- Cable | Yellow / YouTube / Repeat |
| Power AUX2 | SHIFT + Power |
| Play/ Save AUX2 | SHIFT + Play / |
| Pause AUX2 | SHIFT + Pause / Step / |
| Stop AUX2 | SHIFT + Stop / |
| Rec AUX2 | SHIFT + Shift + Rec / Rec Mode |
| <</ Tuner - | SHIFT + Shift + << / |
| >>/ Tuner + | SHIFT + Shift + >> / |
| PR- / I << AUX2 | SHIFT + Shift + I << / Preset- |
| PR+/ >>I AUX2 | SHIFT + Shift + >>I / Preset+ |
| Menu AUX2 | SHIFT + Shift + Menu / Home |

| Original | Rechange |
|---|---|
| Up AUX2 | SHIFT + Shift + Up |
| Left / RDS AUX2 | SHIFT + Shift + Left |
| OK AUX2 | SHIFT + Shift + OK |
| Right / PTY AUX2 | SHIFT + Shift + Right |
| Clear AUX2 | SHIFT + Shift + Exit / Cancel / Clear |
| Down AUX2 | SHIFT + Shift + Down |
| Back/ St - Mono | SHIFT + Shift + Back / Return |
| PR+/ >>I AUX2 | SHIFT + Shift + CH+ / |
| PR- / I << AUX2 | SHIFT + Shift + CH- / |
| 1 AUX2 | SHIFT + Shift + 1 |
| 2 AUX2 | SHIFT + Shift + 2 |
| 3 AUX2 | SHIFT + Shift + 3 |
| 4 AUX2 | SHIFT + Shift + 4 |
| 5 AUX2 | SHIFT + Shift + 5 |
| 6 AUX2 | SHIFT + Shift + 6 |
| 7 AUX2 | SHIFT + Shift + 7 |
| 8 AUX2 | SHIFT + Shift + 8 |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| 9 AUX2 | SHIFT + 9 | | |
| Gui de AUX2 | SHIFT + GUIDE EPG | | |
| 0 AUX2 | SHIFT + 0 | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |