Original		Rechange	
STANDBY	Standby	Power	
P/N	P/N	TIMER SLEEP	Sleep / Timer
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
EJECT	Eject	SURROUND	Eject / Surround
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
ANGLE	Angle	ANGLE INFO	Info / Angle

Original		Rechange	
0	0	HDMI - SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
PBC	PBC	FORMAT PICTURE	Picture / Format
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
RETURN	Return	RETURN BACK	Back / Return
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
TITLE	Title	TITLE SOUND	Sound / Title
	Down		Down
MENU	Menu	HOME MENU	Menu / Home
CHANNEL	Channel	LIST SMART	Smart / List
RESET	Reset	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
LANGUAGE	Language	LANG I/II AUDIO	Audio / Lang I/II
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Original		Rechange	Original		Rechange
MARK	Mark	PC FAV MARKER — Fav / Marker / PC	NEXT	>>I	PRESET+ — >>I / Preset+
CLEAR	Clear	CLEAR EXIT CANCEL — Exit / Cancel / Clear			
SLOW	I>/ Slow	SHIFT + SLOW — Shift + Play /			
A-B	↔/ A-B	YouTube REPEAT A-B — Yellow / YouTube / Repeat			
PSCAN	P. Scan	GOTO TEXT — Text / Goto			
MODE	Mode	TOP MENU D.MENU — D. Menu / Top			
DISPLAY	Display	MEDIA DISPLAY — Display / Media			
3D	3D	SHIFT + CD-STB 3 — Shift + 3			
VOL -	Vol -	VOL − — Vol -			
VOL +	Vol +	+ VOL — Vol +			
STOP	Stop	HOLD — Stop / Hold			
STEP	Step	SHIFT + STEP-FREEZE — Shift + Pause / Step /			
PLAY/PAUSE	Play	SLOW — Play / Slow			
PLAY/PAUSE	Pause	STEP-FREEZE — Pause / Step / Freeze			
F.REV	<<	TUNE- — << / Tune-			
F.FWD	>>	TUNE+ — >> / Tune+			
PREV	I <<	PRESET- — I << / Preset-			