

BOMAN
TV
TV310

Mandis Shop S.L.
Sant Cugat del Vallès (Barcelona)
info@mandis.es



Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
	Power		P/Ch +	CH+	
MUTE	Mute		P/Ch -	CH-	
1 ..?	1		VOL +	Vol+	
2 ABC	2		VOL -	Vol-	
3 DEF	3			Up	
4 GHI	4			Down	
5 JKL	5		OK	OK	
6 MNO	6			Left	
7 PQRS	7			Right	
8 TUV	8		MENU	Menu	
9 WXYZ	9		EXIT RETURN	Exit	
0/10	0		TOP MENU	Audio	
GUIDE	P/N		PICT TITLE		
FAV	Game		EPG	EPG	
AUTO/TRK	Sleep			Favorite PR	
SUBT	Guide			Memory	
AV Dvd/Tv	TV/AV		ZOOM	Search	
	PR List			Info	Pause
TEXT	Teletext		RED	Lang	
TV	Tv/Radio		GREEN	-/-- -	
BACK	Back		YELLOW	Mode	
			BLUE	-/-- +	