

SANYO
TV
RC1523101-S0

MANDIS SHOP S.L.
SANT CUGAT DEL VALLES
info@mandis.es



Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
POWER	Power		V	Down	
MUTE	Mute		EXIT	Exit	
1	1		BACK	Back	
2	2		VOL+	Vol+	
3	3		VOL-	Vol-	
4	4		INFO	i	
5	5		FAV(LIST)	Mode	
6	6		CH+	P+	
7	7		CH-	P-	
8	8		TEXT		
9	9		<P		
0	0		...		
VOD	EPG		TV/RADIO		
MENU	Menu		OPT-		
>PLAY			SOURCE		
PAUSE			V-FORMAT		
STOP			WIDE		
RECORD					
<<					
>>					
<<					
>>					
RED	Red				
GREEN	Green				
YELLOW	Yellow				
BLUE	Blue/XX				
MEDIA					
EPG(GUIDE)	-/--				
OK	OK				
^	Up				
<	Left				
>	Right				