































































	Original	Rechange
	Power	 Power
	Source	 SRC
	1	 1
	2	 2
	3	 3
	4	 4
	5	 5
	6	 6
	7	 7
	8	 8
	9	 9
	0	 0
	TTX/MIX	 TEXT
	PRE-CH	 P/C / FAV
	Vol+	 VOL +
	Vol-	 VOL -
	Mute	 MUTE

	Original	Rechange
	P+	 CH +
	P-	 CH -
	CH List	 TV/R
	Content	 Shift + VOD
	Menu	 MENU
	Guide	 -/-- / EPG
	Tools	 OPT+
	Info	 INFO
	Return	 BACK
	Exit	 EXIT
	Up	 UP
	Down	 DOWN
	Right	 RIGHT
	Left	 LEFT
	Enter	 OK
	Red	 Red (A)
	Green	 Green (B)





Original		Recharge		Original	Recharge
	Yellow		Yellow (C)		
	Blue		Blue (D)		
	Media. P		MEDIA		
	Internet/@TV		VOD		
	Dual I-II		Audio		
	AD		WIDE		
	P.Size		V-FOR		
	Subt.		Subt.		
	<<		Rewind		
	Pause		Pause		
	>>		Fast Forward		
	Rec		Rec		
	Play		Play		
	Stop		Stop		

