



Original	Rechange
Power	Power
My Apps	Media
TV/Radio	TV/R
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
List	List
Q.View	Format
Input	AV
Q.Menu/Subtitle	Subt

Original	Rechange
Guide	Guide
Info	Info
Mute	Mute
Vol+	Vol +
Vol-	Vol -
Page+	Ch +
Page-	Ch -
Text	Text
T.Opt	Options
Smart	Smart
FAV	Pre Ch
Back	Back
Exit	Exit
OK	Ok
Up	Up
Down	Down
Right	Right



