



















































Original	Rechange	Original	Rechange
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TTX/MIX		Text
	PRE-CH		Pre Ch
	Mute		Mute
	CH-List		Guide
	Vol+		Vol +

Original	Rechange	Original	Rechange
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Tools		Options
	Media.P		Media
	Ball		Smart
	Info		Info
	Exit		Exit
	Return		Back
	Menu		Menu
	Enter		Ok
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	Red		Red
	Green		Green



