



Original	Rechange
 Power	 Power
 TV/AV	 AV
 Mute	 Mute
 Sleep	 Sleep
 Pic Mode	 Shift + Format
 SND Effect	 Dual
 Wide	 Format
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Rechange
 FAV	 Pre Ch
 List	 List
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 EPG	 Guide
 Back	 Back
 Exit	 Exit
 Menu	 Menu
 Tv/Radio	 TV/R
 Info	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -
 OK	 Ok





Original	Recharge
	Up
	Down
	Right
	Left
	Text
	Subt
	Shift + Dual
	Shift + Info
	D. Menu
	Shift + Subt
	Options
	Shift + Options
	Shift + Menu
	Eject
	Shift + TV/R
	3D

Original	Recharge

