



| | Original | Rechange | Original | Rechange |
|--|-------------|------------------|----------|--------------|
| | Power | On | | Blank |
| | Up | Up | | Hide / Blank |
| | Enter | OK | | Auto / Mode |
| | Down | Down | | Mute / Focus |
| | Right | Right | | Volume |
| | Left | Left | | Vol + |
| | Menu | Menu / Info | | Vol - |
| | Esc | Exit / Lamp | | Page Up |
| | Reset | OFF | | Page Down |
| | Position | K.S. / PIP | | Home |
| | Freeze | Pict / Freeze | | End |
| | Magnify On | KS Up | | |
| | Magnify Off | KS Down | | |
| | Search | SRC / Search | | |
| | Video | 8 / Video | | |
| | RGB | 1 / Point | | |
| | Aspect | Aspect / Re-Sync | | |

