



Original	Recharge
Power	Power
Tv/Radio	TV/Radio /
Subtitle	Subtitle / EQ
*	D.Menu / Top
Cable	AV / Input / RDS
1	1
Live Zoom	Zoom / Size
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
List	Smart / List
Search	Display / Media

Original	Recharge
Guide	Guide / EPG / -/-
0/Quick Access	0
Info	Info / Angle
Vol+	Vol+
Vol-	Vol-
Mute	Mute / Dimmer
P+	CH+ / Page+
P-	CH- / Page-
Home	Menu / Home
Back	Back / Return
Exit	Exit / Cancel / Clear
Text	Text / Goto
Up	Up
Netflix	Shift + Red / Netflix /
Down	Down
Amazon	Shift + Blue / Prime
Right	Right



