





































Original	Rechange
 Power	 Power
 Open/Close	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Prog	 Sleep
 Clear	 Exit
 Step	 Guide
 Instant Replay	 Format
 Instant Skip	 3D

Original	Rechange
 <</<<	 <<
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 >> >>	 >>
 Return	 Back
 []/Menu	 Menu
 Info	 Info
 Disc Menu	 D. Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 A-B/Repeat	 AV
 EZ View	 Smart
 Subtitle	 Subt



