

































Original	Rechange	Original	Rechange
 Power	 Power		
 Source	 AV		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Mute	 Mute		
 Back	 Back		
 Play/Pause	 Play		
 >>	 >>		
 <<	 <<		
 Sound	 Dual		
 Sound Effect	 Options		
 Sound Control	 Subt		
 Bluetooth	 Text		
 Woofer	 Smart		
 Auto Power	 Format		

