








| Original  | Rechange   |
|---|--|
|  Power |  Power                |
|  AV    |  AV / Input / RDS     |
|  Mute  |  Mute / Dimmer        |
|  16:9  |  Picture / Format     |
|  Zoom  |  Zoom / Size          |
|  Subt. |  Subtitle / EQ        |
|  Audio |  Audio / Lang I/II    |
|  1     |  1                    |
|  2     |  2                    |
|  3     |  3                    |
|  FAV   |  Fav / Marker / PC    |
|  4    |  4                   |
|  5   |  5                  |
|  6   |  6                  |
|  EPG |  Guide / EPG / -/-- |
|  7   |  7                  |
|  8   |  8                  |

| Original  | Rechange   |
|---|--|
|  9       |  9                        |
|  Info    |  Info / Angle             |
|  Back    |  Back / Return            |
|  0       |  0                        |
|  Exit    |  Exit / Cancel / Clear    |
|  Menu    |  Menu / Home              |
|  Up      |  Up                       |
|  Left    |  Left                     |
|  OK      |  OK                       |
|  Right   |  Right                    |
|  Down    |  Down                     |
|  Vol-   |  Vol-                    |
|  Vol+  |  Vol+                   |
|  PR-   |  CH- / Page-            |
|  PR+   |  CH+ / Page+            |
|  Red   |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat   |



