







































































Original		Rechange		Original		Rechange	
	Power		Power		9		9
	AV		AV / Input / RDS		Info		Info / Angle
	Mute		Mute / Dimmer		Back		Back / Return
	16:9		Picture / Format		0		0
	Zoom		Zoom / Size		Exit		Exit / Cancel / Clear
	Subt.		Subtitle / EQ		Menu		Menu / Home
	Audio		Audio / Lang I/II		Up		Up
	1		1		Left		Left
	2		2		OK		OK
	3		3		Right		Right
	FAV		Fav / Marker / PC		Down		Down
	4		4		Vol-		Vol-
	5		5		Vol+		Vol+
	6		6		PR-		CH- / Page-
	EPG		Guide / EPG / -/--		PR+		CH+ / Page+
	7		7		Red		Red / Netflix / Search
	8		8		Green		Green / APP / Repeat



