































































Original		Rechange		Original		Rechange	
	Power		Power		PR +		Ch +
	Menu		Menu		PR-		Ch -
	Q.Menu		D. Menu		i		Info
	Exit		Exit		Guide/Tv+Book		Shift + Options
	Back		Back		1		1
	Red		Red		2		2
	Green		Green		3		3
	Yellow		Yellow		4		4
	Blue		Blue		5		5
	OK		Ok		6		6
	Up		Up		7		7
	Down		Down		8		8
	Right		Right		9		9
	Left		Left		0		0
	Mute		Mute		Recall		Pre Ch
	Vol+		Vol +		TV		TV/R
	Vol-		Vol -		[≡]/Text		Text





Original		Recharge		Original		Recharge	
	*/o..		Eject				
	Source/Game		AV				
	*/o		List				
	World		Guide				
	Music/Movie/Phot		Options				
	[-O-]		Sleep				
	[≡]..		Subt				
	Lang		Dual				
	Rec		Rec				
	Stop		Stop				
	Pause		Pause				
	Play		Play				
	>>		>>				
	<<		<<				

