












































	Original	Rechange
	Power	 Power
	Mute	 Mute
	Screen	 3D
	Tv / AV	 AV
	1	 1
	2	 2
	3	 3
	4	 4
	5	 5
	6	 6
	7	 7
	8	 8
	9	 9
	0	 0
	-/--	 +  Shift + Guide
	Return	 Back
	Pause	 Pause

	Original	Rechange
	Play	 Play
	Stop	 Stop
	Rec	 Rec
	Up	 Up
	Down	 Down
	Right	 Right
	Left	 Left
	OK	 Ok
	CH+	 Ch +
	CH-	 Ch -
	Vol+	 Vol +
	Vol-	 Vol -
	Tv-Menu	 Menu
	Exit	 Exit
	Info	 Info
	Subtitle	 Subt
	Picture	 +  Shift + Format





	Original	Rechange	Original	Rechange
	Sound	 Dual		
	Nicam / A2	 Media		
	Sleep	 Sleep		
	EPG	 Guide		
	FAV	 Pre Ch		
	Channel List	 List		
	Tv / Radio	 TV/R		
	<<	 <<		
	Text	 Text		
	>> / Hold	 >>		
	I<<	 I<<		
	Size	 Format		
	>>I / Index	 >>I		
	Red	 Red		
	Green	 Green		
	Yellow	 Yellow		
	Blue	 Blue		

