






















































































Original	Recharge
 Mute	 Mute / Dimmer
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Swap	 Setup / OPT /
 0	 0
 AV	 AV / Input / RDS
 []	 Shift + 1
 ♪	 Sound / Title
 [<>]	 Picture / Format

Original	Recharge
 [i]	 Info / Angle
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Vol+	 Vol+
 Text	 Text / Goto
 Menu	 Menu / Home
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Back	 Back / Return
 Tv/Exit	 TV/Radio /





	Original	Recharge	
	CH-	 CH- / Page-	
	FAV	 Fav / Marker / PC	
	Subtitle	 Subtitle / EQ	
	Audio	 Audio / Lang I/II	
	Guide	 Guide / EPG / -/--	
	[?]	 Shift + Info / Angle	
	[≡x]	 Shift + 5	
	[:≡]	 Shift + 4	
	[⇅]	 Shift + 3	
	[⇅]	 Shift + 2	
	PIP Pos	 D.Menu / Top	
	PIP Size	 Zoom / Size	
	PIP	 Eject / Surround	

	Original	Recharge

