



































Original	Rechange
 Power	 Power
 Rec	 Rec / Rec Mode
 Red	 Red / Netflix / Search
 I<<	 I<< / Preset-
 Green/[]	 Green / APP / Repeat
 Stop	 Stop / Hold
 Yellow	 Yellow / YouTube / Repeat
 Play/[]	 Play / Slow
 Blue/[]	 Blue / Prime Video / Random
 >>I	 >>I / Preset+
 AV/[?]	 AV / Input / RDS
 I-II/[]	 Audio / Lang I/II
 [<>]/[+]	 Picture / Format
 [-S-]	 Zoom / Size
 Menu	 Menu / Home
 []	 Text / Goto
 Pause	 Pause / Step / Freeze

Original	Rechange
 Left	 Left
 Up	 Up
 Right	 Right
 OK	 OK
 Down	 Down
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 P+	 CH+ / Page+
 Vol-	 Vol-
 Smart J	 Sound / Title
 P-	 CH- / Page-
 Smart []	 Smart / List
 1	 1
 2	 2
 3	 3
 4	 4
5	5







Original	Recharge
0	Eject / Surround
-0-	Subtitle / EQ
Power	Power
Rec	Rec / Rec Mode
I<<	I<< / Preset-
Red	Red / Netflix / Search
Green/[[]]	Green / APP / Repeat
Stop	Stop / Hold
Play	Play / Slow
Yellow / List	Yellow / YouTube / Repeat
>>I	>>I / Preset+
AV/[?]	AV / Input / RDS
I-II/[≡≡]	Audio / Lang I/II
[<>]/[+]	Zoom / Size
PIP [■]	Picture / Format
Menu	Menu / Home
Pause	Pause / Step / Freeze

Original	Recharge
[≡]	Text / Goto
Left	Left
Up	Up
Right	Right
OK	OK
Down	Down
Vol+	Vol+
Mute	Mute / Dimmer
P+	CH+ / Page+
Vol-	Vol-
Smart J	Sound / Title
P-	CH- / Page-
Smart []	Smart / List
1	1
2	2
3	3
4	4





Original	Rechange
 Power	 Power
 -0-	 Subtitle / EQ
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 AV/[?]	 AV / Input / RDS
 I-II/[≡ ≡]	 Audio / Lang I/II
 [<>]/[+]	 Zoom / Size
 Pause	 Pause / Step / Freeze
 [≡]	 Text / Goto
 Left	 Left
 Up	 Up
 Right	 Right
 OK	 OK
 Down	 Down
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 P+	 CH+ / Page+

Original	Rechange
 Vol-	 Vol-
 Smart J	 Sound / Title
 P-	 CH- / Page-
 Smart []	 Smart / List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 P<P	 Fav / Marker / PC

