











Original	Rechange
 Power	 Power
 Mute	 Mute
 Zoom	 Eject
 FAV	 Pre Ch
 FAV+	 Vol +
 FAV-	 Vol -
 Info	 Info
 P/N	 Smart
 Page+	 Ch +
 Page-	 Ch -
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok

Original	Rechange
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Subtitle	 Subt
 Text	 Text
 [+]	 Options
 Tv/Radio	 TV/R
 Recall	 Back
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8





	Original	Rechange		Original	Rechange
	9		9		
	0		0		
	Audio		Dual		
	EPG		Guide		
	<<		<<		
	Play		Play		
	>>		>>		
	Stop		Stop		
	Pause		Pause		
	I<<		I<<		
	>>I		>>I		
	Rec		Rec		
	Rec List		List		

	Original	Rechange		Original	Rechange

