



Original		Rechange		Original		Rechange	
	Power		Power		CH+		Ch +
	Source		AV		CH-		Ch -
	1		1		Menu		Menu
	2		2		Back		Back
	3		3		Info		Info
	4		4		OK		Ok
	5		5		Up		Up
	6		6		Down		Down
	7		7		Right		Right
	8		8		Left		Left
	9		9		SAP		Media
	0		0		Mode/Auto		Options
	PREV.CH		Pre Ch		Freeze		Pause
	.		Guide		Sleep		Sleep
	Mute		Mute		Format		Format
	Vol+		Vol +				
	Vol-		Vol -				

