



































































Original	Recharge	Original	Recharge
 Power	 Power	 <<	 <<
 Eject	 Eject	 Play	 Play
 Tv/VCR	 TV/R	 >>	 >>
 AV	 AV	 Pause/Still	 Pause
 CM Skip	 Options	 Stop	 Stop
 ez Power Off	 Smart	 LP	 Media
 ez Repeat	 Text	 C.Lock	 Back
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 i	 Info
 6	 6	 OK/CLK/CNT	 Ok
 7	 7	 Clear	 Exit
 8	 8	 Rec/OTR	 Rec
 9	 9		
 0	 0		

Original	Recharge	Original	Recharge
 MUTE	 MUTE	 TV	 AUX
 TV	 DVD	 SAT	 REC MODE
 AV	 PLAY MODE	 PLAY	 PLAY
 CM SKIP	 STOP	 PAUSE	 PAUSE
 ez Power Off	 HOME SMART	 DISC NAV LIST	 SOUND DUAL
 ez Repeat	 REPEAT TEXT	 AD SUBT	 SETTINGS OPT
 1	 1	 PICTURE ECO	 3D
 2	 2	 E-MANUAL D.MENU	 TIMER AV
 3	 3	 REPEAT	 ZOOM
 4	 4	 ZOOM	 TIMER AV
 5	 5	 TOP MENU MENU	 DISPLAY INFO
 6	 6	 OK	 OK
 7	 7	 EXIT	 EXIT
 8	 8	 HOME SMART	 HOME SMART
 9	 9	 APP MEDIA	 APP MEDIA
 0	 0	 VOL +	 VOL +
		 VOL -	 VOL -
		 1	 2
		 2	 3
		 3	 4
		 4	 5
		 5	 6
		 6	 7
		7	8
		8	9
		9	0
		0	A
		0	B
		0	C
		0	D

