















































































Original	Rechange	Original	Rechange
 Power	 Power	 Up	 Up
 [≡i]/Info	 Info	 Down	 Down
 Mute	 Mute	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 Enter	 Ok
 3	 3	 Index	 Media
 4	 4	 List	 List
 5	 5	 CH+	 Ch +
 6	 6	 CH-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 ♥	 Pre Ch
 0	 0	 Sleep	 Sleep
 [≡?]/Source	 AV	 EPG	 Guide
 (O/I/II/Audio	 Dual	 Recall	 Back
 Menu	 Menu	 Red	 Red
 Exit	 Exit	 <<	 <<

Original	Rechange	Original	Rechange
 Up	 Up	 Up	 Up
 Down	 Down	 Down	 Down
 Right	 Right	 Right	 Right
 Left	 Left	 Left	 Left
 Enter	 Ok	 Enter	 Ok
 Index	 Media	 Index	 Media
 List	 List	 List	 List
 CH+	 Ch +	 CH+	 Ch +
 CH-	 Ch -	 CH-	 Ch -
 Vol+	 Vol +	 VOL+	 Vol +
 Vol-	 Vol -	 VOL-	 Vol -
 ♥	 Pre Ch	 ♥	 Pre Ch
 Sleep	 Sleep	 SLEEP	 Sleep
 EPG	 Guide	 EPG	 Guide
 Recall	 Back	 Recall	 Back
 Red	 Red	 Red	 Red
 <<	 <<	 <<	 <<





	Original	Rechange	Original	Rechange
	>>		>>	
	Green		Green	
	Yellow		Yellow	
	<<		<<	
	>>		>>	
	Blue		Blue	
	[≡]		Text	
	Play		Play	
	Pause		Pause	
	Stop/Still		Stop	
	[≡+]		Format	
	Radio		TV/R	
	[≡◆]/[+]		3D	
	[≡x]		Options	
	[≡O]/Subtitle		Subt	
	DMP		Smart	
	Rec		Rec	

