







































































Original		Rechange		Original		Rechange	
	Power		Power		CH.List		List
	Mute		Mute		Exit/Cancel		Exit
	1		1		FAV		Shift + Pre Ch
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		OK		Ok
	7		7		CH+/Page+		Ch +
	8		8		CH-/Page-		Ch -
	9		9		S.Mode		Shift + Dual
	0		0		P.Mode		Format
	Display		Info		Vol+		Vol +
	Recall		Pre Ch		Vol-		Vol -
	Setup		Options		Record		Rec
	EPG		Guide		Record List		Smart
	Source		AV		Audio		Dual





Original		Rechange		Original		Rechange	
	S.Title/Subtitle		Subt		Hold/Title		Back
	Reveal		Menu		Zoom-		Shift + Down
	Index		3D		Size/Zoom+		Shift + Up
	Mix		Shift + Subt		Eject		Eject
	Text		Text		Sleep		Sleep
	Play		Play		Scaler		Media
	Pause		Pause		Tv/Radio		TV/R
	Stop		Stop				
	<<		<<				
	>>		>>				
	I<<		I<<				
	>>I		>>I				
	Red/Goto		Red				
	Green/A-B		Green				
	Yellow/Repeat		Yellow				
	Blue/Angle		Blue				
	S.Page/DVD		D. Menu				

