


















































































Original		Rechange		Original		Rechange	
	Power		Power		Exit		Exit
	Mute		Mute		Up		Up
	1		1		CH+		Ch +
	2		2		CH-		Ch -
	3		3		Vol+		Vol +
	4		4		Vol-		Vol -
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		Ok		Ok
	9		9		Subtitle		Subt
	0		0		Text		Text
	FAV		Pre Ch		Play		Play
	Recall		Back		Pause		Pause
	Game		Media		<<		<<
	Tv/Radio		TV/R		>>		>>
	Menu		Menu		I<<		I<<





	Original	Rechange	Original	Rechange
	>>I		>>I	
	EPG		Guide	
	Info		Info	
	Zoom		Eject	
	Audio		Dual	
	Red		Red	
	Green		Green	
	Yellow		Yellow	
	Blue		Blue	

