







































































Original	Recharge	Original	Recharge
 Power	 Power	 Left	 Left
 Mute	 Mute	 OK	 Ok
 1	 1	 P+	 Ch +
 2	 2	 P-	 Ch -
 3	 3	 Vol+	 Vol +
 4	 4	 Vol-	 Vol -
 5	 5	 SAT	 Smart
 6	 6	 FAV	 Pre Ch
 7	 7	 EPG	 Guide
 8	 8	 [] / M	 Dual
 9	 9	 Tv/AV	 AV
 0	 0	 Play	 Play
 Menu	 Menu	 Pause	 Pause
 Exit	 Exit	 Back	 Back
 Up/CH+	 Up	 UHF	 TV/R
 Down/CH-	 Down	 i	 Info
 Right	 Right	 PAL/NTSC	 Format



