



















































Original	Recharge
 Power	 Power
 Mute	 Mute
 Preset/Album	 Up
 Preset/Album	 Down
 >>	 >>
 <<	 <<
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 RDS	 Subt
 Display	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 1	 1
 2	 2
 3	 3
 4	 4

Original	Recharge
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Prog/Clock SET	 Options
 Repeat/Shuffle	 Text
 Sleep/Timer	 Sleep
 DSC	 Smart
 DBB	 Media













































Original	Recharge
 Power	 Power
 Mute	 Mute
 Preset/Album	 Up
 Preset/Album	 Down
 >>	 >>
 <<	 <<
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 RDS	 Subt
 Display	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 1	 1
 2	 2
 3	 3
 4	 4

Original	Recharge
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Prog/Clock SET	 Options
 Repeat/Shuffle	 Text
 Sleep/Timer	 Sleep
 DBB	 Media
 DSC	 Smart






























Original	Rechange
 Power	 Power
 Mute	 Mute
 Preset/Album	 Up
 Preset/Album	 Down
 >>	 >>
 <<	 <<
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 RDS	 Subt
 Display	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 1	 1
 2	 2
 3	 3
 4	 4

Original	Rechange
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Prog/Clock SET	 Options
 Sleep/Timer	 Sleep
 Repeat/Shuffle	 Text
 DSC	 Menu
 DBB	 Back





Original	Rechange
 Power	 Power
 Mute	 Mute
 Preset/Album	 Up
 Preset/Album	 Down
 >>	 >>
 <<	 <<
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 RDS	 Subt
 Display	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 1	 1
 2	 2
 3	 3
 4	 4

Original	Rechange
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Prog/Clock SET	 Options
 DBB	 Media
 DSC	 Smart
 Sleep/Timer	 Sleep
 Repeat/Shuffle	 Text

