







































































Original		Rechange		Original		Rechange	
	Power		Power		Vol+		Vol +
	Subtitle		Subt		Vol-		Vol -
	[ ]/Ratio		3D		Mute		Mute
	Input		AV		FAV		Pre Ch
	Tv/Radio		TV/R		Guide		Guide
	1		1		P+		Ch +
	2		2		P-		Ch -
	3		3		Info		Info
	4		4		Smart		Smart
	5		5		My APPS		Media
	6		6		Back		Back
	7		7		Settings		Options
	8		8		Exit		Exit
	9		9		Up		Up
	0		0		Down		Down
	List		List		Right		Right
	Q.View		D. Menu		Left		Left



