



	Original	Recharge		Original	Recharge
	Sleep	 Sleep / Timer		Pause	 Pause / Step / Freeze
	Standby	 Power		Stop	 Stop / Hold
	Display	 Display / Media		Clear	 Exit / Cancel / Clear
	Clock/Timer	 D.Menu / Top		Vol+	 Vol+
	Clock/Timer Set	 Setup / OPT /		Enter	 OK
	Tuner Memory	 Smart / List		EQ	 Subtitle / EQ
	Play Mode/Tuning Mode	 TV/Radio /		Vol-	 Vol-
	Repeat/FM	 Green / APP / Repeat		Folder-	 CH- / Page-
	USB	 8		Folder+	 CH+ / Page+
	CD	 3			
	Band/Tuner	 6			
	Function	 Menu / Home			
	I<</-	 I<< / Preset-			
	>>I/+	 >>I / Preset+			
	<</←	 << / Tune-			
	>>/→	 >> / Tune+			
	Play	 Play / Slow			

	Original	Recharge		Original	Recharge
	Pause	 Pause / Step / Freeze		Stop	 Stop / Hold
	Clear	 Exit / Cancel / Clear		Vol+	 Vol+
	Vol+	 Vol+		Enter	 OK
	EQ	 Subtitle / EQ		Vol-	 Vol-
	Folder-	 CH- / Page-		Folder+	 CH+ / Page+

