







































































Original	Rechange	Original	Rechange
 Power	 Power	 i/Status	 Info
 1	 1	 X/Exit	 Exit
 2	 2	 Option	 Options
 3	 3	 Return	 Back
 4	 4	 Play/x1.3	 Play
 5	 5	 Pause/Pause Live	 Pause
 6	 6	 Stop	 Stop
 7	 7	 >>	 >>
 8	 8	  <<	  <<
 9	 9	 <</Remind Live	 <<
 0	 0	 >>	 >>
 Radio/Tv	 TV/R	 Rec	 Rec
 Last View	 Pre Ch	 Function Menu	 Menu
 CH/Page+	 Ch +	 Direct Navigator/PopUp	 List
 CH/Page-	 Ch -	 OK	 Ok
 Internet	 Smart	 Up	 Up
 Guide	 Guide	 Down	 Down



