



















































































































Original		Rechange		Original		Rechange	
	Power		Power		6		6
	Audio Monitor		Audio / Lang I/II		7		7
	Wide		Picture / Format		8		8
	Tv/Video		TV/Radio /		9		9
	[≡]		Text / Goto		-/--		Guide / EPG / -/--
	Tv/Video		AV / Input / RDS		0		0
	Vol+		Vol+		Red		Red / Netflix / Search
	[]		Info / Angle		Green		Green / APP / Repeat
	Prog+		CH+ / Page+		Yellow		Yellow / YouTube / Repeat
	Vol-		Vol-		Blue		Blue / Prime Video / Random
	Display		Display / Media				
	Prog-		CH- / Page-				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				





Original		Rechange		Original		Rechange	
	Eject		Eject / Surround		4		4
	Power		Power		5		5
	Audio Monitor		Audio / Lang I/II		6		6
	Wide		Picture / Format		7		7
	Counter Remain		Yellow / YouTube / Repeat		8		8
	[I]		Info / Angle		9		9
	I> Slow		Shift + Play /		-/--		Guide / EPG / -/--
	X2		Shift + >> /		0		0
	I<< Index Search		I<< / Preset-		Input Select		AV / Input / RDS
	Index Search >>I		>>I / Preset+		Vol+		Vol+
	Display		Display / Media		Prog+		CH+ / Page+
	SP/LP		Green / APP / Repeat		Vol-		Vol-
	Clear		Exit / Cancel / Clear		Prog-		CH- / Page-
	Tv/Video		TV/Radio /		Rec		Rec / Rec Mode
	1		1		Pause		Pause / Step / Freeze
	2		2		Up		Up
	3		3		Timer		Sleep / Timer



