

















































Original	Recharge	Original	Recharge
 Power	 Power	 3D	 3D
 Back	 Back	 123/Input	 Media
 Home	 Smart	 Mute	 Mute
 TV	 TV/R	 Mouse Up	 >>
 Micro	 Dual	 Mouse Down	 <<
 Up	 Up	 OK	 Ok
 Down	 Down		
 Left	 Left		
 Right	 Right		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Vol+	 Vol +		
 Vol-	 Vol -		
 P+	 Ch +		
 P-	 Ch -		

