











| Original  | Rechange | Original  | Rechange              |
|---|----------|---|-----------------------|
|    | Power    |    | Power                 |
|    | Source   |    | AV / Input / RDS      |
|    | 1        |    | 1                     |
|    | 2        |    | 2                     |
|    | 3        |    | 3                     |
|    | 4        |    | 4                     |
|    | 5        |    | 5                     |
|    | 6        |    | 6                     |
|    | 7        |    | 7                     |
|   | 8        |   | 8                     |
|  | 9        |  | 9                     |
|  | 0        |  | 0                     |
|  | Guide    |  | Guide / EPG / -/--    |
|  | Return   |  | Back / Return         |
|  | Eco      |  | D.Menu / Top          |
|  | Menu     |  | Menu / Home           |
|  | Exit     |  | Exit / Cancel / Clear |

| Original  | Rechange    | Original  | Rechange               |
|---|-------------|---|------------------------|
|    | Option      |    | Setup / OPT /          |
|    | OK          |    | OK                     |
|    | Up          |    | Up                     |
|    | Down        |    | Down                   |
|    | PR+         |    | CH+ / Page+            |
|    | Right/Zoom+ |    | Right                  |
|    | Left/Zoom-  |    | Left                   |
|    | PR-         |    | CH- / Page-            |
|    | Info        |    | Info / Angle           |
|   | Mute        |   | Mute / Dimmer          |
|  | Vol+        |  | Vol+                   |
|  | Vol-        |  | Vol-                   |
|  | Text        |  | Text / Goto            |
|  | Subtitle    |  | Subtitle / EQ          |
|  | List        |  | Smart / List           |
|  | Red         |  | Red / Netflix / Search |
|  | TV          |  | Display / Media        |



