



Original	Recharge
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Pause	 Pause
 Recall	 Back
 Fav	 Pre Ch
 Menu	 Menu
 i	 Info

Original	Recharge
 EPG	 Guide
 Sat	 Smart
 Exit	 Exit
 Up	 Up
 Prog +	 Ch +
 Down	 Down
 Prog -	 Ch -
 Right	 Right
 Vol +	 Vol +
 Left	 Left
 Vol -	 Vol -
 Ok	 Ok
 TV / Radio	 TV/R
 Zoom	 Eject
 Page -	 <<
 Page -	 I<<
 Help	 D. Menu





Original		Recharge	
	F1		Options
	Page +		>>
	Page +		>>
	UHF		Format
	P/N		3D
	TV/SAT		Media
	Subtitles		Subt
	Audio		Dual
	Red / Audio		Red
	Green / Mosaic		Green
	Yellow / Clock		Yellow
	Blue / Text		Blue
	Text		Text

Original		Recharge	

