
































































Original		Rechange		Original		Rechange	
	Power		Power		Green/Zoom		Green
	1		1		Yellow		Yellow
	2		2		Blue/[<>]		Blue
	3		3		[i]		Info
	4		4		Back		Back
	5		5		TXT		Text
	6		6		Menu		Menu
	7		7		TV-G		Guide
	8		8		Top Menu		Shift + Menu
	9		9		P+		Ch +
	0		0		P-		Ch -
	AV		AV		Vol+		Vol +
	?		Options		Vol-		Vol -
	[...]		Subt		Up		Up
	Audio		Dual		Down		Down
	Mute		Mute		Right		Right
	Red		Red		Left		Left
































































Original	Rechange	Original	Rechange
	OK		Ok
	I</Sound		I<<
	>I/Picture		>>I
	<<		<<
	>>		>>
	Rec/I>		Rec
	Play		Play
	Pause		Pause
	Stop		Stop
	List		List
	FAV		Pre Ch
	@		Media
	3D		3D
	CEC		TV/R





Original		Recharge		Original		Recharge	
	Power		Power		Green/Zoom		Green
	1		1		Yellow		Yellow
	2		2		Blue/[<>]		Blue
	3		3		[i]		Info
	4		4		Back		Back
	5		5		Menu		Menu
	6		6		TXT		Text
	7		7		TV-G		Guide
	8		8		Top Menu		Shift + Menu
	9		9		P+		Ch +
	0		0		P-		Ch -
	AV		AV		Vol+		Vol +
	?		Options		Vol-		Vol -
	[...]		Subt		Up		Up
	Audio		Dual		Down		Down
	Mute		Mute		Right		Right
	Red		Red		Left		Left







































































Original		Recharge		Original		Recharge	
	OK		Ok				
	I</Sound		I<<				
	>I/Picture		>>I				
	<<		<<				
	>>		>>				
	Rec/I>		Rec				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	List		List				
	FAV		Pre Ch				
	@		Media				
	3D		3D				
	CEC		TV/R				





Original		Recharge		Original		Recharge	
	Power		Power		Green/Zoom		Green
	1		1		Yellow		Yellow
	2		2		Blue/[<>]		Blue
	3		3		[i]		Info
	4		4		Back		Back
	5		5		TXT		Text
	6		6		Menu		Menu
	7		7		TV-G		Guide
	8		8		Top Menu		Shift + Menu
	9		9		P+		Ch +
	0		0		P-		Ch -
	AV		AV		Vol+		Vol +
	?		Options		Vol-		Vol -
	[...]		Subt		Up		Up
	Audio		Dual		Down		Down
	Mute		Mute		Right		Right
	Red		Red		Left		Left























































Original	Recharge	Original	Recharge
	OK		Ok
	I</Sound		I<<
	>I/Picture		>>I
	<<		<<
	>>		>>
	Rec/I>		Rec
	Play		Play
	Pause		Pause
	Stop		Stop
	List		List
	FAV		Pre Ch
	@		Media
	3D		3D
	CEC		TV/R





Original		Rechange		Original		Rechange	
	Power		Power		Green/Zoom		Green
	1		1		Yellow		Yellow
	2		2		Blue/[<>]		Blue
	3		3		[i]		Info
	4		4		Back		Back
	5		5		Menu		Menu
	6		6		TXT		Text
	7		7		TV-G		Guide
	8		8		Top Menu		Shift + Menu
	9		9		P+		Ch +
	0		0		P-		Ch -
	AV		AV		Vol+		Vol +
	?		Options		Vol-		Vol -
	[...]		Subt		Up		Up
	Audio		Dual		Down		Down
	Mute		Mute		Right		Right
	Red		Red		Left		Left





Original	Recharge
OK	Ok
I</Sound	I<<
>I/Picture	>>I
<<	<<
>>	>>
Rec/I>	Rec
Play	Play
Pause	Pause
Stop	Stop
List	List
FAV	Pre Ch
@	Media
3D	3D
CEC	TV/R

Original	Recharge

