















































































































Original	Rechange
 PIP/[]	 Picture / Format
 Web	 Smart / List
 Back/End	 Exit / Cancel / Clear
 DR+/Pop-Up-M	 D.Menu / Top
 */Zoom	 Zoom / Size
 Blue/Marker	 Blue / Prime Video / Random
 Red	 Red / Netflix / Search
 Text/Disc-M	 Text / Goto
 Info	 Info / Angle
 Vol+	 Vol+
 Vol-	 Vol-
 P+	 CH+ / Page+
 P-	 CH- / Page-
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left

Original	Rechange
 OK	 OK
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 <<	 << / Tune-
 Play	 Play / Slow
 >>	 >> / Tune+
 Rec	 Rec / Rec Mode
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 7	 7
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6









































































Original	Rechange
 Mute	 Mute / Dimmer
 Power	 Power
 DR+/Pop-Up-M	 D.Menu / Top
 */Zoom	 Zoom / Size
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 AV	 AV / Input / RDS
 EPG	 Guide / EPG / -/--
 Home	 Menu / Home

Original	Rechange
 PIP/[]	 Picture / Format
 Text	 Text / Goto
 Back	 Back / Return
 Info	 Info / Angle
 Vol+	 Vol+
 P+	 CH+ / Page+
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Vol-	 Vol-
 Down	 Down
 P-	 CH- / Page-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue/Marker	 Blue / Prime Video / Random













































Original	Recharge
 DR+/Pop-Up-M	 D.Menu / Top
 */Zoom	 Zoom / Size
 Blue/Marker	 Blue / Prime Video / Random
 Back/End	 Exit / Cancel / Clear
 PIP/[]	 Picture / Format
 Red	 Red / Netflix / Search
 Info	 Info / Angle
 Vol+	 Vol+
 Vol-	 Vol-
 P+	 CH+ / Page+
 P-	 CH- / Page-
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 OK
 Green	 Green / APP / Repeat

Original	Recharge
 Yellow	 Yellow / YouTube / Repeat
 <<	 << / Tune-
 Play	 Play / Slow
 >>	 >> / Tune+
 Rec	 Rec / Rec Mode
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 7	 7
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 Power	 Power
 8	 8





Original	Rechange
 Mute	 Mute / Dimmer
 Power	 Power
 DR+/Pop-Up-M	 D.Menu / Top
 */Zoom	 Zoom / Size
 Web	 Smart / List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0 AV	 AV / Input / RDS
 EPG	 Guide / EPG / -/-

Original	Rechange
 Home	 Shift + Menu /
 PIP/[]	 Picture / Format
 Text	 Text / Goto
 Menu	 Menu / Home
 Back/End	 Exit / Cancel / Clear
 Info	 Info / Angle
 Vol+	 Vol+
 P+	 CH+ / Page+
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Vol-	 Vol-
 Down	 Down
 P-	 CH- / Page-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat



